



How to Change the UI language to English

Article ID: GV28-13-03-12-k

Release Date: 03/12/2013

Applied to

GV-DVR / NVR System
GV-System
GV-Fast Backup and Restore Multicam System
ViewLog / EZViewlog
GV-Remote ViewLog
GV-POS Text Sender
GV-IP Device Utility

GV-Central Monitoring Station
GV-Center V2
GV-Vital Sign Monitor
GV-Dispatch Server
GV-Control Center
GV-Remote E-Map

Digital Signage
CMS Lite


Summary

The **SetLanguage** application can be applied to any of the above software and applications in order to change the default regional UI language to English. Follow the below steps for installation.




Installation


1. Download the SetLanguage application from <http://ftp.geovision.tw/ftp/Chung/Patch/SetLanguage.zip>.
2. Run the downloaded file and install to your computer.
3. Close the open Geovision software and application.
4. At the Start menu, click the **SetLanguage** icon.



5. When the Configure window appears, use the Language drop-down list to select **English**.



6. Click **OK** and restart your Geovision software or application to use it in English user interface.






Returning to default UI language

If you want to return your UI language to the default setting, follow the below steps.

1. Close the open Geovision software and application.
2. At the Start menu, click the **SetLanguage** icon.
3. When the Configure window appears, use the Language drop-down list to select **Default**.



4. Click **OK** and restart your Geovision software or application to use it in default user interface.