



Comparison between GV-Enterprise and GV-Authentication Server

Software	GV-Enterprise	GV-Authentication Server
License	GV-Control Center V4 license required (USB dongle only)	No license required
User Level		
Guest	X	V
User	V	V
Power User	V	V
Supervisor	V	V
VMS Settings		
Monitor Start	V	V
Monitor Stop	V	V
Network Start	V	V
Network Stop	V	V
Schedule Start	V	V
Schedule Stop	V	V
Input State	V	V
Output Control	V	V
PTZ	V	V
System Setting	V	V
Video Attribute	V	V
Object Tracking	V	V
Edit Password	V	V
Minimize or Logout	V	V
Snapshot	V	V
Exit System	V	V
Layout Setup	V	V
Live Text Overlay	V	X
Search POS Data	V	X
Enable/disable live view for each channel	X	V
Enable/disable live audio for each channel	X	V
ViewLog Settings		
Export AVI	V	V
Delete Event Log	V	V
Browse System Log	V	V
Backup Event Log	V	V
Display Detected Faces	V	V
Enable/disable each ViewLog channel	X	V
Enable/disable each ViewLog audio channel	X	V
WebCam Settings		
Input State	V	X
Output Control	V	X
PTZ	V	V
RPB	V	V
Talkback	V	V
E-Map	V	V
Monitor Start (GV-Eye)	V	X
Monitor Stop (GV-Eye)	V	X
Video Attribute	V	X
System Configure	V	X
File Save and Snapshot	V	V



Software	GV-Enterprise	GV-Authentication Server
Limit Connection Time	V	V
Enable/disable channel on WebCam and GV-Eye	X	V
Enable/disable audio channel on WebCam and GV-Eye	X	V
Control Center Settings		
Service Start	V	V
Service Stop	V	V
System Configure	V	V
Control Center Service Access	V	V
Remote Desktop Access	V	V
Remote Desktop Deny	V	V
Remote ViewLog	V	V
Limit Connection Time (GV-ERM)	V	V
Privacy Mask Settings		
Restore Recoverable Video	V	V
Enable/disable channel for Restore Recoverable Video	X	V
Others		
Execute Repair Log	V	V
Disable Live Alarm	V	V
Active Directory	V	V

All specifications are subject to change without notice.