



**Comparison Chart for GV-Eye / GV-iView / GV-AView**

Model	<a href="#">GV-Eye</a>	<a href="#">GV-iView</a>	<a href="#">GV-AView</a>
Versions	<b>V2.2</b>	<b>V2.3.2 / HD V1.2.2 (for iOS)</b>	<b>V1.3.1 (for Android)</b>
<b>Software</b>			
Supported OS	iOS 8 ~ 9.1 Android 4.0 ~ 5.1.1	iOS 4.3.3 or later	Android 2.2 or later
Resolution	Up to 12 MP	VGA / CIF	
Codec	MPEG4, MJPEG and H.264	MJPEG	
<b>Hosts</b>			
GV-DVR/NVR	V8.6.2.0	V8.6.2.0	V8.6.2.0
GV-VMS	V14.10	No	
GV-Mobile Server	V1.4.2.0		
GV-Recording Server	V1.2.5.0		
GV-SNVR	V1.10		
GV-IP Camera	Yes		
GV-Video Server	Yes		
GV-Compact DVR	Yes		
<b>Features</b>			
Snapshot	Yes		
PIP	Yes		
Recording	Yes		
2-Way Audio	Yes	No	
PTZ	Yes		
Fisheye Dewarping	Yes *An in-app purchase	No	
I/O Trigger	Yes		
Speaker	Yes	No	
Stream Switch	Yes	No	
Hardware Decode (Android)	Yes	No	
Remote Playback	Yes		
<b>License</b>			
Max. number of channels	2, 4, 6, 8, 9, 12, or 16 channels x 6 pages Up to 96 live views	6 channels x 6 pages Up to 32 live views	

All specifications are subject to change without notice.

**Note for GV-Eye V2.2:**

1. The following functions will be supported in a future version.
  - Enabling recording and triggering I/O devices of GV-VMS V15.10
  - Controlling PTZ cameras from GV-SNVR
2. Recording can be enabled with the following GV-Video Server only.
  - GV-VS04A (Firmware V1.06 or later)
  - GV-VS11 (Firmware V1.03 or later)
  - GV-VS12 (Firmware V1.07 or later)
  - GV-VS14 (Firmware V1.01 or later)
3. Assigning NAS storage path is supported by the following GV-IP Cameras only.
  - GV-Target IP Cameras (Firmware V1.02 or later)
  - GV-IP Cameras (Firmware V3.0 or later)
4. To access audio from GV-Mobile Server using GV-Eye, install GV-Mobile Server and GV-DNR/NVR on the same computer.